03/22/2022

Yibei Huang

```
C:\Users\huangxipconfig
Windows IP Configuration

Ethernet adapter Ethernet:

Media State . . . . . : Media disconnected
Connection-specific DNS Suffix . :

Wireless LAN adapter Local Area Connection* 2:

Media State . . . . . : Media disconnected
Connection-specific DNS Suffix . :

Wireless LAN adapter Local Area Connection* 3:

Media State . . . . . : Media disconnected
Connection-specific DNS Suffix . :

Wireless LAN adapter Local Area Connection* 3:

Media State . . . . : Media disconnected
Connection-specific DNS Suffix . :

Wireless LAN adapter Wi-Fi:

Connection-specific DNS Suffix . :

Link-local IPv6 Address . . : fe80::f4c6:a3fc:2281:4c2f%18
IPv6 Address . . . : 192.168.31.230
Subnet Mask . . . . : 255.255.255.0
Default Gateway . . . : 192.168.31.1
```

```
UDPClientSocket = socket(family=AF_INET, type=SOCK_DGRAM)

UDPClientSocket.settimeout(1)
server_addr = (host, port)
resps = []
```

- 1. Create the client socket and set the type as UDP.
- 2. Set the time out to 1 second.
- 3. Create server address and port tuple.
- 4. Create an empty list to store future responds from server.

```
try:
    start_time = time.time()
    message = "Ping " + str(seq) + " " + str(start_time)

UDPClientSocket.sendto(message.encode(), server_addr)

data, server = UDPClientSocket.recvfrom(4096)
    resps.append((seq_data.decode()_float(data.decode().split()[3]) - float(data.decode().split()[2])))
    # Fill in end

except timeout:

    resps.append((seq_m"Request timed out"_n0))
    print("Ping " + str(seq) + " request timed out")
```

- 1. For each iteration, record client's send time
- 2. Create message to send to the server
- 3. Send the message through the socket
- 4. Receive responds from the server
- 5. Store sequence number, server respond and calculated rtt to the list if got a respond
- 6. If timed out, store the timed out information in the list.

The extra credit Ping Statistics was completed in file <cli>exercise1.py>.